

**Trickle Vents in Sashes**

When Glazpart Link Vents are supplied fitted to the sash rather than to the outer frame, an additional installation step is required to ensure proper functionality and a secure fit. In this configuration, the clip-in lugs on the internal vent must be removed, and the internal vent will then need to be fixed in place using screws.

This modification is necessary because the internal routing within the sash is designed to accommodate a narrower 8 mm slot, as opposed to the standard 13 mm slot typically available when fitting vents to the outer frame. Due to this reduced slot size, the clip-in lugs cannot be used effectively, and the screw-fixing method provides a reliable alternative.

By following this approach, the vent can be installed correctly while maintaining aesthetic requirements however overall performance is marginally reduced owing to the limitations imposed by the smaller slot size.